

Fitting Tips

Inner tube replacement:

- Using tyre levers carefully remove the tyre and tube
- Feel around the inside of the tyre and ensure any sharp objects are removed
- Feel around the wheel rim to ensure there is no damage/sharp edges etc
- Fit the first side of the tyre onto the rim
- Inflate the new tube just enough to shape it
- Insert the tube into the tyre with the valve in line with the valve hole in the rim
- Push the valve into the valve hole
- Work the second side of the tyre onto the rim using your fingers

DO NOT USE ANY TOOLS TO FIT THE TYRE BACK ONTO THE RIM, USE ONLY YOUR HANDS.

- Make sure the tyre is sitting evenly around the rim
- Inflate a little at a time, always checking the tyre is sitting evenly

These tips also apply to fitting a new tyre, the only difference being you don't need to check the new tyre for sharp objects.

If you are still unsure about fitting your new tyre/tube please feel free to call us on:

01733 561550

Fitting Tyre Liners:

- Tuck the tyre liner inside the tyre
- Overlap the end by approx 1" (25mm) and cut
- Use a small piece of adhesive tape over the join to keep it in place
- Put a couple of pumps of air in the inner tube (just enough to shape it)
- Put the inner tube inside the tyre so it holds the liner in place
- Fit one side of the tyre onto the wheel, at the same time insert the valve through the valve hole
- Push the second side of the tyre over the wheel rim using your thumbs
- Ensure the tyre is sitting evenly on the wheel rim and inflate to full pressure

You can also find more information on our website:

<http://www.oybicycles.com/HELP>

On Yer Bike

541 Lincoln Road

Peterborough PE1 2PB

Tel: 01733 561550

Email: info@oybicycles.com

Web: www.oybicycles.com